

# SURFACE / FLUSH MOUNT LOCK - RESIDENT EMPLOYEE MODE: WESKO LOCK APP

DOWNLOAD / REGISTER THE APP

DOWNLOAD 'WESKO LOCK APP'



Register

CLICK 'NEW? SIGN UP HERE'

## FIND YOUR eLock

### USE 'FIND ME' PAIRING

- A. ON KEYPAD PRESS
- B. TAP ON TOP BAR THEN "Scan for eLocks"
- C. FIND GREEN TILE ON APP SCREEN

OR

### USE APP

FIND YOUR LOCK  
ON APP SCREEN



### CHANGE PASSCODE

1. ON YOUR TILE, TAP
2. ENTER YOUR NEW PASSCODE AND SAVE

## LOCK / UNLOCK



TO LOCK

1. TURN THE KNOB TO LOCK POSITION
2. TAP ICON TO LOCK
3. TILE TURNS BLUE



TO UNLOCK

1. TAP ICON TO UNLOCK
2. ICON CHANGES TO UNLOCK
3. TURN KNOB TO UNLOCK POSITION

## CHARGING

LOW BATTERY















PLUG IN USB CHARGER

# SURFACE / FLUSH MOUNT ELOCK - RESIDENT EMPLOYEE MODE: Keypad

## FIRST TIME USE

<b>CHANGE DEFAULT PASSCODE</b>	 1. PRESS 3, THEN P (YELLOW LED TURNS ON)	 2. ENTER '1234' THEN PRESS 	 3. ENTER ANY 4 DIGITS THEN PRESS  FOR NEW PASSCODE (GREEN LED BLINKS AND YELLOW TURNS OFF)
--------------------------------	--	---	--

## DAILY USE

 <b>TO UNLOCK</b>	 1. ENTER PASSCODE, PRESS 	 2. TURN THE KNOB TO UNLOCK POSITION
 <b>TO LOCK</b>	 1. TURN THE KNOB BACK TO LOCK POSITION	 2. PRESS  TO LOCK
 <b>BATTERY LEVEL</b>	 <b>PRESS 2, THEN P</b>	<p><b>LED STATUS INDICATOR</b></p>   <b>PLUG IN USB CHARGER</b>